

Figure 1




Figure 2

Figure 3

82

Select Vehicle Group: All Vehicles

Reg. No.	Alt. ID	Type/Grp.	Last Position	Date	Batt.	DTC	Weeks to Service
GHJ 564	4912	Kapell	Västerås	031102	5	OK	18
MMD 781	4516	Kapell	Göteborg	031101	4	OK	3
GWU 934	3845	Skåp	Helsingborg	031102	5	OK	8
BNJ 765	4610	Kapell	Jönköping	031102	5	OK	-1
KLU 664	3987	Skåp	Borlänge	031101	3	OK	5
PLD 903	4312	Skåp	Stockholm	031101	5	OK	16
HUL 644	4119	Skåp	Falun	031101	4	OK	7
OFH 904	2798	Kapell	Strängnäs	031101	5	OK	1
JWS 786	4260	Kapell	Köpenhamn	031102	5	OK	12
HGD 607	4188	Skåp	Sundsvall	031102	3	PK	9
BNJ 765	4610	Skåp	Helsingfors	031101	4	OK	7

84 = No report received from vehicle for more than 24 hours

88 = No vehicle movement registered in more than 72 hours

86 = No vehicle movement registered in more than 24 hours

To view vehicles' last position on map, select vehicle(s) and press **SHOW ON MAP**




Figure 4
90